

powered by NAVITAS

Vehicle Operating System

On-the-Fly Programmer Quick Start Guide

Range Control Lower the speed and increase your range. The controller automatically reconfigures to run more efficiently at lower speeds.

Speed Adjust your vehicle's top speed.

Key Lock Lock to set golf car at desired speed; disable the dials until the system is unlocked.



Regen Control regenerative braking for safety and efficiency.

Acceleration

Adjust how fast your vehicle accelerates.

Safety Warnings

- Do not leave children or pets unattended in or near the vehicles.
- Never drive too fast. The terrain, conditions, and the operator's skill should determine a safe speed.
- Drive at a reduced speed and use extra caution when carrying passengers or cargo.
- · Avoid sharp turns and do not accelerate quickly when turning.
- · Always look behind you before and while backing up.
- Reduce speed when towing and allow more room for stopping and turning.
- Drive with wheels straight when going up and down hills.
- · Slow down and use brakes when going down hills.
- Never drive on hills with a slope greater than 15 degrees.
- Do not drive through running water or water above the floor of the vehicle.
- If you must cross shallow water, make sure to stop and inspect the

- area for sudden drop-offs, large rocks or slippery surfaces. Always proceed with caution or choose a safer route.
- When towing this vehicle make sure the vehicle is turned off, the Run/ Tow switch is in Tow, and the batteries' main power is disconnected.
- Never exceed the towing capacity rating as specified by the vehicle manufacturer.
- Keep electrical components dry and DO NOT wash with direct stream or pressure washer.
- Never rewire, bypass, or change the wires, switches, or controller.
 Contact your dealer or the manufacturer if the vehicle is not operating correctly.
- Keep the controller and the area around it clean and free of debris.
- Vehicle and all parts must be serviced by qualified service personnel.
 For an authorize service location see your local dealer or visit www.starev.com/dealer-locator/ to find your closest dealer.



JH Global Services, Inc.

Phone: (864) 297-8833 Toll Free: (888) 878-9988

378 Neely Ferry Rd, Simpsonville, SC 29680